


HTC VIVE CHECKOUT CART


Vive BOX	Cart
Headset x1	Keyboard x1
Headphones x1	Mouse x1
Controllers x2	USB Speakers x1
Infrared Sensors x2	Dell Monitor x1
Microfiber Cloth x1	Tripods x2
External Hard Drive (My passport) Plus cable x1	Tripod adapter x2
5W USB Charger x2	Ethernet cord x1
USB type C x2	Cyberpower Desktop PC x1
Infrared Sensor Power supply x2	VR - PC box x1

Basic Setup Instructions

1. Set up the tripods with the infrared stations diagonal from each other, approximately 5 meters apart. Make sure the corners are close to a power outlet.
2. Set the cart up at the top most edge of your VR space.
3. Plug the headset into the small box on the cart labeled “PC ↓ VR ↑”
4. Power Computer on and log into CCA account. Password is CCA.
5. Open steam

- a. Click the  button in the top right corner.

- b. Hold the  button on the VIVE controllers to connect them to the computer.

- c. Once everything is green 
- d. Click the words “Steam VR” on the top of the SteamVR window, and click “Run Room Setup” Follow the instructions from there.